

INSTRUCTION

- 1) 2 HEX BOLTS 1/2" X 1 3/4"
- 2) 2 FLAT WASHER 1/2"
- 3) 2 LOCKNUTS 1/2"
- 4) 8 CARRIAGE BOLTS 3/8" X 1"
- 5) 8 LOCK NUTS 3/8"

- A) 1 TOP
- B) 1 BACK
- C) 2 SIDE WALLS
- D) 1 DOOR HASP
- E) 1 HINGE ANGLE
- F) 1 DOOR
- G) 4 FEET

GAS CYLINDER CAGE
ASSEMBLY INSTRUCTIONS

INSTRUCTIONS


1-THESE DRAWINGS SHOW THE ASSEMBLY OF THE CAGE. THIS DRAWING SHOWS LEFT HANDED ACCESS. FOR RIGHT HANDED ACCESS INVERT BOTH HINGE ANGLE AND DOOR HASP, SEE ITEMS D AND E.

2-ATTACH TOP, BACK, BOTH SIDE WALLS AND DOOR HINGE TOGETHER USING 3/8" CARRIAGE BOLTS AND 3/8" LOCK NUTS. LEAVE BOLTS LOOSE TO ALLOW FOR ADJUSTMENTS.

3-INSTALL DOOR TO THE HINGE USING 1/2" HEX BOLTS, 1/2" WASHERS AND 1/2" LOCK NUTS. THE WASHER IS PLACED BETWEEN THE HINGE AND DOOR TO ALLOW THE DOOR TO SWING SMOOTHLY. LEAVE BOLTS LOOSE TO ALLOW ADJUSTMENTS.

4-ATTACH FEET TO THE CAGE ASSEMBLY WITH 3/8" CARRIAGE BOLTS AND 3/8" LOCK NUTS. FEET ALLOW THE CAGE TO BE BOLTED TO THE FLOOR.
(CONCRETE ANCHOR BOLTS NOT INCLUDED).

5-ENSURE THE GAS CYLINDER CAGE IS SQUARE AND TIGHTEN ALL BOLTS IN PLACE.



DETAIL I
SEE NOTE I

KLETON